

Anziehvorschrift Zylinderkopf**Tightening Instructions for Cylinder Head****Instructions de serrage pour culasse****Prescripciones de apriete para culatas****012.361**passend für / suitable for
adaptable à / adaptable a**Renault / Nissan****Das Original**Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo759.350
M 9x1,25x103Anziehen/
Tightening/
Serrage/
Apriete

- 1.
- 20 Nm
 - 90°±6°
 - 3 min
 - Pos. 1/2:
 - 20 Nm
 - 200°±6°

- 2.
- Pos. 3/4/5/6:
 - 20 Nm
 - 200°±6°
 - Pos. 7/8/9/10:
 - 20 Nm
 - 200°±6°

Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

÷ 1,27 mm, Ø 70 mm

Mot.: D7D 700/740, D7F 700-704/706/710/720/
722/726/730/744/746/764/766Clio, Kangoo, Twingo
Kubistar**Elring-Serviceteam**Fon +49 7123 724 799
Fax +49 7123 724 798
service@elring.de

24/01/22

012.361