

Anziehvorschrift Zylinderkopf**Tightening Instructions for Cylinder Head****Instructions de serrage pour culasse****Prescripciones de apriete para culatas****153.142**passend für / suitable for
adaptable à / adaptable a**PSA, Fiat, Ford, Volvo****Das Original**Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo267.551
M 12x1,5x121Anziehen/
Tightening/
Serrage/
Apriete

PSA DW10ATED4

- 20 Nm
- 60 Nm
- 60 Nm
- 110°
- 110°

PSA DW12TED4

- 20 Nm
- 60 Nm
- 20 Nm
- 60 Nm
- 110°
- 110°

Fiat, Ford, Volvo

- 30 Nm
- 60 Nm
- 220°

Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

÷ 1,35 mm, Ø 86 mm, 3 Löcher/holes/trous/agujeros

Mot.: G6DA, G6DB, G6DC, G6DD, G6DE, G6DF, AZWA
 QXWA, QXWB, DW10ATED4, DW10BTED4, DW12TED4
 RHR, RHK/DW10UTED4, D4202T/T2

Focus, C-Max / 307, 406, 407, 607, 807
 V40II, V50 / C4, C5, C8

Elring-Serviceteam

Fon +49 7123 724 799
 Fax +49 7123 724 798
service@elring.de

24/11/12

153.142