


<b>Anziehvorschrift für Zylinderkopf</b>	<b>431.341</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		
	passend für / suitable for adaptable à / adaptable a	<b>PSA</b>

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



267.550  
M 12x1,5x126



Anziehen/ Tightening/ Serrage/ Apriete	Citroen: Jumper	Peugeot: Boxer
*	22 Nm	* 22 Nm
	60 Nm	60 Nm
□	360°	□ 360°
	60 Nm	60 Nm
➤	220°	➤ 110°
		➤ 110°

**Zeichenerklärung / Explanations / Explication / Explicacion**

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Ø 86 mm,  $\frac{1}{4}$  1,35 mm, 3 Löcher

Mot: 4HY, DW12UTED

2,2 Itr. HDi

74 kW (101 PS)

Boxer, Jumper

ab 2002→

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*431.341\***