


Anziehvorschrift für Zylinderkopf		252.980	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a VW	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
864.450 M 12x1,75x209			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤ ➤	30 Nm 70 Nm 90° 90° 90°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
✚ 1,71mm Ø 82mm 3-Loch/holes/trous/agujero			
Mot.: 2,0l TDI EA288 evo			
A4, A5, A6, Q5			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*252.980*	