

Anziehvorschrift für Zylinderkopf		123.032	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a Citroën/Peugeot/Renault	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
152.570 M 10x1,5x148			
Anziehen/ Tightening/ Serrage/ Apriete	* ☐ ➤	20 Nm 15 Nm 225°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
⚙ 0,74 mm, Ø 89 mm, rechts/right/droite/derecha			
Mot.: ES9J4S, ES9A, XFV, XFW, XFX, L7X 710, 721, 731-733, 760 3,0 Ltr. V6 150-166 KW			
C5, C6, C8, Ulysse, Phedra, 406, 807 Avantime, Clio			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*123.032*	