

# INSTALLATION INSTRUCTIONS



A 000 142 10 89 (MERCEDES-BENZ)



**Fig.1**

1. Point the filter element towards the housing.  
Use the grease on the outer and inner gaskets.



**Fig.2**

2. Screw the filter element in the housing using 80Nm torque.