

Anziehvorschrift Zylinderkopf**Tightening Instructions for Cylinder Head****Instructions de serrage pour culasse****Prescripciones de apriete para culatas****454.860**passend für / suitable for
adaptable à / adaptable a**Dodge/Jeep****Das Original**Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo

| | | |
|---|--|--|
| Anziehen/ Tightening/ Serrage/ Apriete | <ul style="list-style-type: none"> ⊙ M11 1-10 / 15 ft-lb ⊙ M11 1-10 / 35 ft-lb ⊙ M8 11-14 / 18 ft-lb ➤ M11 1-10 / 90° ➤ M8 11-14 / 22 ft-lb | <ul style="list-style-type: none"> M11 1-10 / 20 Nm M11 1-10 / 48 Nm M8 11-14 / 25 Nm M11 1-10 / 90° M8 11-14 / 30 Nm |
|---|--|--|

Zeichenerklärung / Explanations / Explication / Explicacion

| | | | | |
|---|---|------------------------------|--------------------------------|---------------------------------------|
| | neue Zylinderkopf-schrauben verwenden | use new cylinder head bolts | utiliser des vis neuves | emplar tornillos nuevos |
| * | Warmlauf (80°C) | warm up time (80°C) | chauffage (80°C) | calentamiento (80°C) |
| | Schrauben einzeln lösen und wieder anziehen | loosen and tighten each bolt | deserrer et serrer vis par vis | aflojar y apretar tornillo a tornillo |
| ● | Setzzeit | relaxation time | durée de tassement | tiempo de espera |
| ➤ | Drehwinkel | torque angle | angle de serrage | ángulo de giro |

Motortyp / Engine type / Type de moteur / Tipo de motor

Dodge Dakota 2003-2000 4.7L V8 287cid

Dodge Ram 1500 2003-2002 4.7L V8 287cid

Jeep Grand Cherokee 2003-1999 4.7L V8 287cid

Dodge Durango 2003-2000 4.7L V8 287cid

Elring-Serviceteam

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

24/01/22

454.860