

STEP 1

SELECT YOUR WIPER
ARM CONNECTION

STEP 2

FIND THE MATCHING
ADAPTER

STEP 3

INSTALL YOUR REAR WIPER BLADE
FOLLOWING THE INSTRUCTIONS BELOW

ø 7.0*12mm



2118



ø 7.0*12mm



2119



ø 4.0*11mm



2120



ø 4.0*11mm



2121



ø 4.0*11mm



2121



ø 7.0*11mm



2122



ø 4.0*11mm



2125



15mm



2142



15mm



2124



11mm



2166



13mm



2167

