


**Anziehvorschrift Zylinderkopf****Tightening Instructions for Cylinder Head****Instructions de serrage pour culasse****Prescripciones de apriete para culatas****590.490**passend für / suitable for  
adaptable à / adaptable a**Chrysler/Dodge****Das Original**Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornilloAnziehen/  
Tightening/  
Serrage/  
Apriete

- M11 1-8 / 45 lb-ft
- M11 1-8 / 65 lb-ft
- M11 1-8 / 65 lb-ft
- M11 1-8 / 90°
- M8 9 / 10 lb-ft
- M8 9 / 15 lb-ft
- M8 9 / 25 lb-ft

- M11 1-8 / 60 Nm
- M11 1-8 / 90 Nm
- M11 1-8 / 90 Nm
- M11 1-8 / 90°
- M8 9 / 12 Nm
- M8 9 / 20 Nm
- M8 9 / 35 Nm

Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Chrysler Town &amp; Country 2010-2004 3.3L V6 201cid

Dodge Grand Caravan 2010-2004 3.3L V6 201cid

Dodge Caravan 2007-2004 3.3L V6 201cid

**Elring-Serviceteam**

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

24/01/22

**\*590.490\***