

Anziehvorschrift für Zylinderkopf		245.620 passend für / suitable for adaptable à / adaptable a Audi	 Das Original																
Tightening Instructions for Cylinder Head																			
Instructions de serrage pour culasse																			
Prescripciones de apriete para culatas																			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete																	
 586.360 M 12x1,5x175		<table border="1"><tr><td>7</td><td>1</td><td>4</td><td>6</td></tr><tr><td>5</td><td>3</td><td>2</td><td>8</td></tr><tr><td>5</td><td>3</td><td>2</td><td>8</td></tr><tr><td>7</td><td>1</td><td>4</td><td>6</td></tr></table>		7	1	4	6	5	3	2	8	5	3	2	8	7	1	4	6
7	1	4	6																
5	3	2	8																
5	3	2	8																
7	1	4	6																
Anziehen/ Tightening/ Serrage/ Apriete		* 35 Nm 70 Nm ➤ 90° ➤ 90°																	
Zeichenerklärung / Explanations / Explication / Explicacion																			
* neue Zylinderkopf-schrauben verwenden		use new cylinder head bolts																	
★ Warmlauf (80°C)		warm up time (80°C)																	
☐ Schrauben einzeln lösen und wieder anziehen		loosen and tighten each bolt																	
● Setzzeit		relaxation time																	
➤ Drehwinkel		torque angle																	
utiliser des vis neuves		emplar tornillos nuevos																	
chauffage (80°C)		calentamiento (80°C)																	
deserrer et serrer vis par vis		aflojar y apretar tornillo a tornillo																	
durée de tassement		tiempo de espera																	
angle de serrage		ángulo de giro																	
Motortyp / Engine type / Type de moteur / Tipo de motor																			
3,0 TDI 1,59 mm rechts/right																			
Mot. CVUA, CVUB, CVUC, DEHA																			
235/240/250 KW (320/326/340 PS)																			
A6, A6 allroad, A7, SQ5																			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*245.620*																	