

EINBAUHINWEIS VW AMAROK VORDERACHSE- FITTING NOTE VW AMAROK FRONT AXLE



Einbau

Original-/ BILSTEIN Anbauteile in umgekehrter Reihenfolge, analog zum Ausbau, auf BILSTEIN- Federbein montieren.

Vor dem Entspannen der Feder ist darauf zu achten, dass die Federenden korrekt in den Ausschnitten des oberen und unteren Federtellers anliegen!

Das komplettierte BILSTEIN- Federbein in umgekehrter Reihenfolge analog zum Ausbau wieder montieren.

Aufgrund einer kurzzeitigen Produktionschwierigkeit ist es möglich, dass, zusätzlich zum BILSTEIN Lieferumfang, diese Ersatzmutter M12x1 anstelle der notwendigen Original Mutter M12x1,5 (16,5mm hoch) montiert werden muss. Die Original Mutter entfällt damit.

Installing

Fit original/ BILSTEIN mounting parts on strut in reverse order as removal.

Before releasing the spring, care is to be taken to ensure that the spring rests in the cut outs of top and bottom spring plate!

Fit assembled BILSTEIN strut to the vehicle in reverse order as removal.

Due to a short-term production difficulty, it is possible that, in addition to the BILSTEIN scope of delivery, this replacement nut M12x1 must be fitted instead of the necessary original nut M12x1.5 (16.5mm high). The original nut is therefore no longer required.

thyssenkrupp Bilstein GmbH
Milsper Straße 214; D-58256 Ennepetal
Postfach 1151, D-58240 Ennepetal
Phone: +49 2333 791-4444
Fax: +49 2333 791-4400
info@bilstein.de, www.bilstein.de