

RANCHO

PERFORMANCE SUSPENSION & SHOCKS



SWAY BAR SPACER KIT RS861000

Front - TOYOTA LANDCRUISER 78,79 Series (1999 on)
76 Series (2007 on)

IMPORTANT: These components must be fitted to factory specifications by qualified persons.

This sway bar spacer kit is required to ensure adequate clearance between front sway bar and front drive shaft at full suspension hang, for vehicles fitted with longer travel front shock absorbers associated with a 40 to 50mm front suspension lift.

Kit Contents:

- Qty 2 Spacer Plates (12 mm)
- Qty 4 Hex Bolts (M8 x 1.25 x 35 mm)
- Qty 4 Flat Washers (M8)
- Qty 4 Spring Washers (M8)

Fitting Instructions:

1. Position 1 x spacer plate supplied, between each front sway bar mounting plate and sway bar D-clamp, as shown Pic 1.
2. Use new (longer) bolts and washers supplied.
3. Ensure new spring washers are positioned to bolt head.

Picture 1.



Sway Bar Spacer

