Metzger
AUTOTEILE

WICHTIGER MONTAGEHINWEIS

Nockenwellenversteller 0899036, 0899066

- Die Führungshülse zur Öldrucksteuerung in der Nockenwelle muss verbaut sein! Andernfalls ist kein ausreichender Öldruck vorhanden. Im Motorsteuergerät wird ein Fehler abgelegt und der Versteller wird nicht aktiviert.
- Laufrichtungsgebundene Kette muss korrekt eingebaut werden. Markierung auf Kette!
- Sieb der Ölpumpe auf Ölschlamm und andere Ablagerungen prüfen und ggf. reinigen.
- Alle Bestandteile des Kettentriebs auf Verschleiß und Funktion prüfen.
- Bei Mängeln wird das Ersetzen des gesamten Kettentriebs empfohlen.
- Beim Tausch des Nockenwellenverstellers Vorgaben des Fahrzeugherstellers beachten.

#FIRSTTOMARKET

Metzger
AUTOTEILE

IMPORTANT INSTALLATION NOTICE

Camshaft Adjuster 0899036, 0899066

- The guide sleeve for oil pressure control in the camshaft must be installed! Otherwise, there will not be sufficient oil pressure. An error will be logged in the engine control unit and the adjuster will not be activated.
- The directional chain must be installed correctly. Markings on the chain!
- Check the oil pump strainer for oil sludge and other deposits, and clean if necessary.
- If there are defects, replacement of the entire timing chain drive is recommended.
- When replacing the camshaft adjuster, follow the car manufacturer's specifications.

#FIRSTTOMARKET