



**1 987 432 116**

**Land Rover  
Freelander**

**09.97 →**

Pack-Nr. 6 000 435 426

**D** **Innenraumfilter**  
Montageanleitung

**NL** **Interieurfilter**  
Montagehandleiding

**GB** **Cabin filter**  
Installation instructions

**E** **Filtro ventilacion  
para interior**  
Instrucciones de montaje

**F** **Filtre d'habitacle**  
Notice de montage

**P** **Filtro de purificação  
do habitáculo**  
Instruções de montagem

**I** **Filtro abitacolo**  
Istruzioni di montaggio

**S** **Kupéfilter**  
Installationsanvisning

**BOSCH**





