


Anziehvorschrift für Zylinderkopf		123.681	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for	
Instructions de serrage pour culasse		adaptable à / adaptable a	
Prescripciones de apriete para culatas		PSA/Renault	
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
152.570 M 10x1,5x148			
Anziehen/ Tightening/ Serrage/ Apriete	* ☐ ▶	20 Nm 15 Nm 225°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ▶	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
✚ 1,65 mm, Ø 89 mm, rechts/right/droite/derecha			
Mot.: ES9J4, XFZ, L7X 700,701,713,727 3,0 Ltr. V6 24V, 150 KW (190 PS)			
Xantia, XM, 406, 605 Espace, Laguna, Safrane			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*123.681*	