

Anziehvorschrift für Zylinderkopf		061.151 passend für / suitable for adaptable à / adaptable a Alfa Romeo / Fiat	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			

Schraubenkopf / Head shape
 Tête de vis / Cabeza de tornillo

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



9	7	1	3	5	11
12	6	4	2	8	10

497.410
 M 12X1,25X224

Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤ ➤	65 Nm 90° 90° 90°
---	------------------	----------------------------

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

✚ 0,95 mm, Ø 83 mm

Mot.: 939 A3.000, 939 A9.000
 2,4 ltr. Diesel JTD
 147-154 kW (200-210 PS)

159,166, Brera, Spider, Croma

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601	*061.151*
--	-----------