

Anziehvorschrift für Zylinderkopf		939.060 passend für / suitable for adaptable à / adaptable a Nissan	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
7 5 2 4 10 9 3 1 6 8 ○ ○ ○ ○ ○ 9 3 1 6 8 7 5 2 4 10 ○ ○ ○ ○ ○ Bank 2 Bank 1			
Anziehen/ Tightening/ Serrage/ Apriete	* ☐ ➤ ➤	98 Nm 44 Nm 60° 60°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor Ø: 98mm Mot. VK56DE 5,6 ltr Patrol, Titan, Armada, Pathfinder, NV2500 HD, NV3500 HD, NV Passanger, GT-R GT1, Altima			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*939.060*	