

- Ⓓ Wechselintervall alle ...
- ⒼⒷ Replacement interval ...
- Ⓘ Sostituzione dopo ...
- Ⓕ Intervalle de remplacement ...
- Ⓔ Intervalle de cambio ...
- ⒸⓁ Vervanging elke ...

15.000 KM /

10.000 MI

- Ⓓ ... oder nach 1 Jahr
- ⒼⒷ ... or after 1 year
- Ⓘ ... or dopo 1 anno
- Ⓕ ... ou 1 fois par an
- Ⓔ ... o después de 1 ano
- ⒸⓁ ... of 1 keer per jaar

BMW 5er (E60)	07.03 →
BMW 5er Touring (E61)	06.04 →
BMW 6er Coupé (E63)	01.04 →
BMW 6er Cabrio (E64)	04.04 →

21653064 / CC1138 / MC 666-2
21653063 / CP1138 / MP 166-2

Einbauanleitung

Innenraumfilter

Fitting instructions

Cabin air filter

Istruzioni di montaggio

Filtro abitacolo

Notice de montage

Filtre d'habitacle




Instrucciones de montaje

Filtro de habitáculo

Inbouwhandleiding

Interieurfilter

BMW



BMW

