


Anziehvorschrift für Zylinderkopf		187.710	
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a Fiat Das Original	
	Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
152.760 M 12x1,25x218			
Anziehen/ Tightening/ Serrage/ Apriete	* Fiat: 20 Nm 65 Nm ➤ 90° ➤ 90° ➤ 90°	Lancia: * 65 Nm ➤ 90° ➤ 90° ➤ 90°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ □ ● ➤	neue Zylinderkopf-schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
83 mm Ø 1,80 mm ± 2 Löcher			
Mot: 182.A2.000, 838.A3.000, 838.A7.000 2,4 TD			
Marea ab 1996 ➔ Kappa 07/1996 ➔ 10/2001			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*187.710*	