

Anziehvorschrift für Zylinderkopf		568.130	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a PIAGGIO	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
7 4 1 5 3 2 6			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	Pos. 1-6: 45 Nm Pos. 1-6: 90 Nm Pos. 1-6: 90° Pos. 1-6: 90° Pos. 7: 24 Nm	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor PIAGGIO Porter			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*568.130*	