

Service Information XZS168

## Installation position of the pad retaining springs - GDB1732

The TRW brake pad set GDB1732 is supplied with two different versions of pad retaining springs.

The pad retaining spring with rubber coating (charcoal coloured coating) each have to be mounted where the brake disc runs out (arrow) during forward drive.













