

Anziehvorschrift für Zylinderkopf		008.832 passend für / suitable for adaptable à / adaptable a Alfa Romeo / Fiat	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
374.270 M12X1,25X224				
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤ ➤	62 - 68 Nm 90° 90° 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor ✱ 1,02 mm, Ø 83 mm, 2 Löcher/holes/trous/agujeros Mot.: 937A5.000, 939A2.000, 937A8.000, 937A4.000, 192B1.000, 192A5.000 1,9 Ltr. Diesel JTD 16 V Stilo, GT, Croma, 147, 159				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*008.832*		