

- Ⓓ Wechselintervall alle ...
- ⒼⒷ Replacement interval ...
- Ⓘ Sostituzione dopo ...
- Ⓕ Intervalle de remplacement ...
- Ⓔ Intervalle de cambio ...
- ⒸⓁ Vervanging elke ...

15.000 KM /

10.000 MI

- Ⓓ ... oder nach 1 Jahr
- ⒼⒷ ... or after 1 year
- Ⓘ ... or dopo 1 anno
- Ⓕ ... ou 1 fois par an
- Ⓔ ... o después de 1 ano
- ⒸⓁ ... of 1 keer per jaar

<b>Citroen C8</b>	<b>07.02</b> →
<b>Fiat Scudo</b>	<b>01.04</b> →
<b>Fiat Ulysse</b>	<b>08.02</b> →
<b>Lancia Phedra</b>	<b>09.02</b> →
<b>Peugeot 807</b>	<b>06.02</b> →

21653147 / CC1096 / MC 616  
21652856 / CP1096 / MP 116

### Einbauanleitung

Innenraumfilter

### Fitting instructions

Cabin air filter

### Istruzioni di montaggio

Filtro abitacolo

### Notice de montage

Filtre d'habitacle

### Instrucciones de montaje

Filtro de habitáculo

### Inbouwhandleiding

Interieurfilter

